

TECHNICAL DATA REPORT

HS 4074

F-4074

Non-Chlorinated Pot & Pan Detergent

DESCRIPTION:

White free flowing dustless powder suitable for use in mechanical dishwashing equipment.

PURPOSE:

F-4074 is formulated to provide maximum cleaning action on all types of soil from plasticware, china, glass dishware, cutlery and aluminum utensils.

HOW TO USE:

- 1) Clean machine thoroughly, making sure that all wash and rinse arms are free from food or foreign particles.
- 2) **MANUAL:** **F-4074** should be used in a concentration of 2g/L of water at 60-65°C.
- 3) **AUTOMATIC:** Fill dispenser with **F-4074**. The machine will be charged automatically. Do not add **F-4074** to the machine.
- 4) Place dishes evenly in the racks designed for them. **DO NOT** place cups, glasses or bowls one on top of each other. **DO NOT** nest saucers or plates. Keep them separate.
- 5) Let machine take the racks through the wash and rinse cycles. Do not rush them through the machine.

MAIN USERS:

Restaurants, institutions, hospitals, hotels, etc.

ADVANTAGES:

- 1) Completely soluble.
- 2) Free flowing.
- 3) Excellent cleaning action on all types of soil.
- 4) Contains water softening agents which sequester hard water salts, reducing scale build-up in dishwashing machines and film build-up on china and plastics.
- 5) Non-chlorinated to protect aluminum.
- 6) Non-corrosive, even on aluminum.
- 7) Conforms to specification CGSB-2.20-M87
- 8) Completely biodegradable.

PRECAUTIONS:

Avoid contact with eyes, contains alkaline detergents. In case of contact with eyes, flush for 15 minutes with water and get medical attention. Can cause skin irritation, wear rubber gloves when handling undiluted material. Keep out of reach of children. Read Material Safety Data Sheet.

SPECIFICATIONS:

Physical form	White powder
Rinsing	Complete
Foaming	Low
pH @ 5g/Litre	11.5
Solubility	Complete in hard or soft water
Biodegradable	Yes